


- Surface tension and wetting
- Introduction to surfactants
- Emulsions
- Foams







# Surface tension phenomena in daily life



## Surface tension phenomena in daily life

#### Refer to the pictures on slide #2 and discuss in groups

- 1. Sketch the shapes of water drops on:
  - a lotus leaf

- water-repellent fabric
- a windshield

2. What causes the difference between the drop shapes?

3. Why can an insect walk on the surface of a pond?

# Surface tension phenomena on the International Space Station

#### Watch the video:

http://www.youtube.com/watch?v=IMtXfwk7PXg

#### and discuss in groups

1. Sketch the shape of a water drop on Earth and a water drop on the ISS.

2. What is the Bond number on the ISS?

3. Why does the washcloth absorb water even if you are in space?


## Surface tension and wetting

- thermodynamic definition of surface tension
- molecular origin of surface tension
- wetting of a liquid by a liquid
- intermolecular interactions and surface tension
- measuring surface tension
- wetting of a solid by a liquid
- contact angle and Young's law
- measuring contact angle
- contact angle hysteresis
- superhydrophobic surfaces
- capillarity and porous media

#### Surface tension causes fluid interfaces to contract

#### **OBSERVATION:**

- wire loop with a movable slide
- form a liquid film
- slide retracts so as to decrease surface area of film




- need to do work dW to increase area of film by dA
- $dW = \gamma dA$
- $\mathbf{v}$  surface tension
- reversible work => change in Gibbs free energy  $(dG)_{T,P} = \gamma dA$
- surface tension: increase in Gibbs free energy per unit increment of surface area

$$\mathcal{G} = \mathcal{E} \frac{\P G \ddot{0}}{\P A} \dot{\tilde{g}}_{T,P}$$

# Surface tension is the key concept in characterizing fluid interfaces

Units of surface tension: energy per unit area (Joule/m²)

or: force per unit length (N/m)




- need to do work dW to increase area of film by dA = 2Ldx
- force applied: F
- displacement: dx
- $dW = Fdx = \gamma dA = \gamma 2Ldx$

## Surface tension of common liquids

Liquid	γ (mN/m) at 20°C
<i>n-</i> Perfluoro-Pentane	10.3
<i>n-</i> Pentane	16.1
n-Octane	21.8
<i>n</i> -Hexadecane	27.5
Glycol	48
Glycerol	63
Water	73

## Origin of surface tension: intermolecular interactions



### Vapour

### Liquid/Vapour Interface

**cohesive** forces towards the liquid bulk are not balanced


the molecules are attracted inwards

### **Bulk liquid**

**cohesive** forces are balanced in all directions


the molecules do not experience any net force

# Relation between surface tension and work of **cohesion**



- Liquid phase (α)
- Work of cohesion: work required to pull apart a volume of unit cross sectional area (A=1)
- two new surfaces of area A=1 are created
- Work done  $W_{\text{cohesion}} = 2\gamma_{\alpha}$
- $\gamma_{\alpha} = W_{\text{cohesion}}/2$  is surface energy per unit area (or **surface tension**)

### Work of adhesion between different materials



- Phases  $\alpha$  and  $\beta$ : liquid or solid
- Work of adhesion: work required to separate a unit area of interface between two phases (α and β) to form a new surface of each phase
- $W_{\text{adhesion }\alpha\beta} = \gamma_{\alpha} + \gamma_{\beta} \gamma_{\alpha\beta}$
- $\gamma_{\alpha\beta}$  is interfacial energy per unit area (or interfacial tension)

# Work of adhesion affects **spreading** of liquid upon another liquid

What determines whether a liquid spreads to cover the surface of another liquid or remains as an isolated droplet?




olive oil on water: no spreading

- If oil spreads on water, area of oil-water interface increases; area of water-vapor interface decreases
- Change in free energy dG ~  $(\gamma_{ov} + \gamma_{ow} \gamma_{wv})dA$
- Spreading is **spontaneous** if dG < 0, i.e. if  $\gamma_{ov} + \gamma_{ow} \gamma_{wv} < 0$
- **Spreading coefficient**  $S = \gamma_{wv} (\gamma_{ov} + \gamma_{ow}) > 0$  spontaneous spreading
- $S = W_{\text{adhesion oil-water}} W_{\text{cohesion oil}} > 0$  spontaneous spreading
- spontaneous spreading would mean that the oil adheres to the water more strongly than it coheres to itself

## Fluid $\beta$ spreading over fluid $\alpha$

Show that: 
$$S = W_{\text{adhesion }\alpha\beta} - W_{\text{cohesion }\beta}$$




spreading coefficient  $S = \gamma_{\alpha} - (\gamma_{\beta} + \gamma_{\alpha\beta})$ 

$$W_{\text{adhesion }\alpha\beta} =$$

$$W_{\text{cohesion }\beta}$$
 =

## Origin of surface tension: intermolecular interactions



### Vapour

## Liquid/Vapour Interface

**cohesive** forces towards the liquid bulk are not balanced

the molecules are attracted inwards

### **Bulk liquid**

**cohesive** forces are balanced in all directions

the molecules do not experience any net force

## Origin of surface tension: intermolecular interactions

- Cohesive forces in a fluid:
  - van der Waals interactions:
    - between polar molecules: permanent dipole-permanent dipole (Keesom or orientation interaction)
    - between a polar and a non-polar molecule: permanent dipoleinduced dipole (Debye or induction interaction)
    - between ALL molecules: fluctuating dipole-induced dipole (London or dispersion interaction)
  - polar; metallic (e.g. mercury); hydrogen bonding; etc
- Each interaction contributes (approx. independently of each other) to total surface tension:

$$\gamma^{\text{total}} = \gamma^{\text{d}} + \dots + \gamma^{\text{H}} + \dots$$

$$\text{dispersion interactions:} \quad \text{all other interactions specific to liquid under consideration}$$


## Dispersion forces: interaction energy

$$W(r) = -\frac{3}{4} \frac{\alpha^2 I}{(4\pi\varepsilon_0)^2} \frac{1}{r^6}$$
attractive interaction

- $\alpha$  is molecular polarisability
- I is ionisation potential
- $\varepsilon_0$  is permittivity of free space

See: lecture on van der Waals interactions

# Dispersion forces: relationship between Hamaker constant and surface tension



Summation over all the atoms of one medium with all the atoms of the other medium gives interaction energy between two planar surfaces:

$$W(D) = -A/12D^2$$

A: Hamaker constant (bulk property of material)

- If we also sum over all the atoms in the same medium we get:
  - From atoms in bulk: work of cohesion
  - From atoms near interface: surface energy
- Surface energy per unit area:  $\gamma = A/24\pi D_0^2$  (energy needed to separate two flat surfaces from contact to infinity)
- It is found that  $D_0 \sim 0.165$  nm gives predicted values of surface tension in good agreement with experiment

## Surface tension of common liquids - Continued

Liquid	A (10 <sup>-20</sup> J)	$\gamma = A/24\pi D_0^2$	$\gamma$ (mN/m) at 20°C
<i>n</i> -Perfluoro-Pentane	2.59	12.6	10.3
<i>n-</i> Pentane	3.75	18.3	16.1
n-Octane	4.5	21.9	21.8
n-Hexadecane	5.2	24.4	27.5
Glycol	5.6	28	48
Glycerol	6.7	33	63
Water	3.7	18	73

Hamaker simple theory experiment  $(D_0 = 0.165 \text{ nm})$ 

simple theory fails for polar substances because dispersion interactions are not the dominant interactions

## Combining relations: interfacial tension

- What is the relationship between  $\gamma_{\alpha}$ ,  $\gamma_{\beta}$ , and  $\gamma_{\alpha\beta}$ ?
- Fowkes equation, based on assumption that cross-interaction term across interface (work of adhesion) is due exclusively to dispersion forces:

$$\gamma_{\alpha\beta}^{\mathrm{total}} = \gamma_{\alpha}^{\mathrm{total}} + \gamma_{\beta}^{\mathrm{total}} - 2\sqrt{\gamma_{\alpha}^{\mathrm{d}}\gamma_{\beta}^{\mathrm{d}}}$$

- Hydrocarbons only have dispersion interactions, hence:  $\gamma_{hc}^{d} = \gamma_{hc}^{total}$
- Assuming that water interacts with hydrocarbons mainly via dispersion forces, we can apply Fowkes equation.
- EXAMPLE: water-hexane interface.
  - For water:  $\gamma_{\text{water}}^{\text{d}} = 21.8 \text{ mN/m}$  and  $\gamma_{\text{water}}^{\text{total}} = 72.8 \text{ mN/m}$ .
  - For hexane:  $\gamma_{\text{hexane}}^{\text{total}} = 18.4 \text{ mN/m}$ .


  - measured value: 51.1 mN/m.

## Liquid Surface Tension Measurements

#### Du Noüy ring method

- Ring is pulled through liquid surface or liquid-liquid interface until rupture
- Maximum force exerted on the ring,  $F_{max}$ , is measured using a force sensor
- Ring is made of material (e.g. Pt-Ir) that is well wetted by liquid, so that  $\cos\theta\approx 1$
- *L* is wetted length of the ring (inner + outer circumference)


$$\gamma = \frac{F_{\text{max}}}{L\cos\theta}$$



### Wilhelmy plate method

- The force acting on a vertically immersed plate is measured using a force sensor
- Plate is made of material (e.g. Pt) with  $\cos \theta \approx 1$
- L is wetted perimeter on the plate
- Method is suitable to measure interfacial tension as a function of time (interface is not ruptured)

$$\gamma = \frac{F}{L\cos\theta}$$




## Liquid Surface Tension Measurements

#### Pendant drop method

- A drop of the heavier fluid is formed into the lighter fluid (density difference  $\Delta \rho$ )
- Shape is determined by balance between weight of drop and surface tension forces, described by the **Bond number**:

$$Bo = \frac{\Delta \rho \ g \ R^2}{\gamma}$$

- Numerical fit of shape returns surface tension
- If Bo is too large, drop can detach (e.g. very low surface tension)




#### Spinning drop method

- Drop of lighter fluid is formed into heavier fluid (density difference  $\Delta \rho$ )
- During rotation with velocity  $\omega$ , drop shape evolves to form long cylinder of radius R = d/2
- Interfacial tension is calculated from Vonnegut's equation:


$$\gamma = \frac{\Delta \rho \ R^3 \omega^2}{4}$$

• Method for very low surface tension ( $\gamma < 0.1 \text{ mM/m}$ )




# Wetting of a solid by a liquid


A liquid on a solid surface can take one of three configurations:



# Contact Angle $\theta$



Force balance on contact line (per unit length):



### Equilibrium:


$$-g_{sv} + g_{sl} + g_{lv} \cos q = 0$$
$$g_{lv} \cos q = g_{sv} - g_{sl}$$


## Young's equation:

$$\cos Q = \frac{g_{sv} - g_{sl}}{g_{lv}}$$


## Contact angle measurements: sessile drop







## Advancing and receding contact angle




Static (advancing) contact angle



Dynamic contact angle: advancing and receding



Sliding of drop for tilting angle of substrate  $\alpha$ 




Force (per unit length) needed to make a drop slide over a solid surface:

$$f = \frac{\gamma_{lv}(\cos\theta_r - \cos\theta_a)}{2}$$

At angle  $\alpha$ , a liquid drop with perimeter L and mass m slides on a smooth surface. Sliding constant:

$$k_{\alpha} = mg \sin \frac{\alpha}{L}$$

## Contact Angle Hysteresis



Increasing droplet volume→ approaching maximum(advancing) contact angle

Decreasing droplet volume

→ approaching minimum

(receding) contact angle


Contact angle hysteresis:


$$\Delta\theta = \theta_{\rm a} - \theta_{\rm r}$$

is caused by non-ideal surfaces (roughness, chemical heterogeneity)

## Effect of surface roughness

different (apparent) values of  $\theta$  on rough surfaces:





drop in Wenzel state

$$\cos\theta = \frac{\gamma_{sv} - \gamma_{sl}}{\gamma_{lv}}$$

Young's contact angle

$$R_{\rm W} = \frac{A_{\rm true}}{A_{\rm apparent}}$$

roughness factor


#### **Wenzel Equation:**


$$\cos \theta_{\rm W}^* = R_{\rm W} \cos \theta$$


 $\theta_{W}^{*}$ : apparent contact angle

## Effect of chemical heterogeneity

Contact angle is different on different parts of surface







# $\cos\theta_1 = \frac{\gamma_{1v} - \gamma_{1l}}{\gamma_{lv}}$

Young's contact angle on solid surface 1

$$\cos\theta_2 = \frac{\gamma_{2v} - \gamma_{2l}}{\gamma_{lv}}$$

Young's contact angle on solid or fluid surface 2

#### **Cassie-Baxter-Equation:**

 $\theta_{CB}^*$ : apparent contact angle


$$\cos \theta_{\rm CB}^* = f_1 \cos \theta_1 + f_2 \cos \theta_2$$

$$f_1=1-f_2$$
  $f_i$ : surface fractions  $(i=1,2)$ 


images: Wikipedia

## Superhydrophobicity and the Lotus effect










#### Link between roughness and self-cleaning:

- (a) On smooth surfaces, dirt particles are redistributed by water
- (b) On rough surfaces, dirt adheres to drop and is removed from leaves when droplets roll off



## Self-cleaning coatings




Videos: <a href="https://youtu.be/UwoGsCAKsxU?t=7s">https://youtu.be/UwoGsCAKsxU?t=7s</a>
<a href="https://youtu.be/BvTkefJHfC0?t=3m18s">https://youtu.be/BvTkefJHfC0?t=3m18s</a>

**□** • □ €

4,201,602 views


15,763 4 398

## **Capillary Action**



θ< 90°, small surface tension liquid on a high energy surface, water on clean glass

→ adhesive forces are greater than the cohesive forces



 $\theta$  > 90°, large surface tension liquids (such as Hg)

→ Adhesive forces are less than cohesive forces

## Capillary Action


- Pressure under meniscus in capillary is less than atmospheric pressure P: pressure just below curved surface is P-2√r
- liquid rises until weight of column balances surface tension forces (hydrostatic pressure ρgh)
- equilibrium height:

$$h = \frac{2g\cos q}{rgR}$$

## Laplace pressure

 $2\gamma/r$ 

r: radius of curvature of meniscus





## Capillary rise in porous medium

- packed bed (porous medium = foam, fibre bed or textile, powder bed) is brought in contact with liquid phase
- if solid is wetted by liquid, liquid rises due to capillary action in small pores/interstices
- Height (mass) is measured over time t
- Contact angle of porous material can be obtained:


#### Washburn equation:


$$h^2 = \frac{rg_{LV}\cos q}{2h} \times t$$

*r* – effective interstitial pore radius

 $\eta$  – liquid viscosity

 $\gamma_{lv}$  – liquid/vapor surface tension





## Surface tension and wetting

- recall: definition of surface tension
- apply: spreading coefficient
- understand: molecular origin of surface tension
- understand: surface tension components
- apply: Fowkes equation
- apply: equations used in liquid surface tension measurements
- understand: wetting of solids by liquids
- derive and apply: Young's law of contact angle
- recall: contact angle hysteresis
- understand: effect of surface roughness and heterogeneity
- recall: superhydrophobicity
- apply: Wenzel equation and Cassie-Baxter equation
- understand: Laplace pressure and capillary action
- apply: equation for equilibrium height of liquid column in capillary
- apply: Washburn equation for capillary rise method